

# **GEM420 Command Line Format**

Command Line Format .....	1
Introduction .....	3
1. Basic network.....	4
1.1. WAN .....	4
1.1.1. physical interface .....	4
1.1.2. internet setup.....	5
1.2. LAN & VLAN.....	10
1.2.1. Ethernet LAN .....	10
1.3. WiFi .....	10
1.3.1. Configuration .....	10
1.3.2. Wireless Client List .....	12
1.3.3. Advanced Configuration.....	13
1.4. IPV6 .....	13
1.4.1. Configuration .....	13
1.5. NAT/Bridging .....	15
1.5.1. Configuration .....	15
1.5.2. Virtual server & Virtual Computer .....	16
1.5.3. Special AP & ALG .....	16
1.5.4. DMZ.....	17
1.6. Routing.....	18
1.6.1. Static Routing .....	18
1.6.2. Dynamic Routing .....	18
1.6.3. Routing Information .....	19
1.7. Client/Server/Proxy.....	20
1.7.1. Dynamic DNS.....	20
1.7.2. DHCP Server .....	21

# Introduction

The CLI parameters nearly always take the following format. There are only a few exceptions.

<b>Entity</b>	<b>Instance</b>	<b>Parameter</b>	<b>Values</b>	<b>Description</b>
---------------	-----------------	------------------	---------------	--------------------

And need apply to alter.

- Current support apply parameter.
- lan\_ip
- wan\_interne
- routing
- phy\_type
- wps
- wifi\_conf
- nb\_conf
- vs
- vc
- nb\_alg
- ap
- nb\_dmz
- nb\_dr
- dn
- ddns
- fix\_map

Enter command will show the supported parameters.

ex:

```
# ppp
usage:ppp instance parameter
values support parameters:
  userna
  me
  passwor
  d ipaddr
  mask
  gateway
  ppp_server_ip_na
  me conn_id
  username
```

## 1. basic network

### 1.1. WAN

#### 1.1.1. physical interface

Entity	Instance	Parameter	Values	Description
eth	n	phy_iface	0/1/2	0: ethernet 1: 3g/4g 2: usb 3g/4g
eth	n	op_mode	0/1	0: disable 1: always
eth	n	failover	m	n: wan interface (failover wan) m: wan interface (main wan)
eth	n	dis_failover	m	disable failover

				n : wan interface (failover wan) m: wan interface (main wan)
eth	n	seamless	on/off	need failover on
eth	n	line_speed_ul_m	value	Mbps
eth	n	line_speed_dl_m	value	Mbps
eth	n	line_speed_ul	value	Kbps
eth	n	line_speed_dl	value	Kbps
eth	n	vlan_tag	on/off	
eth	n	vid	vlan_id	1~4095
apply	phy_type	n		apply the physical interface alter

### 1.1.2. internet setup

Entity	Instance	Parameter	Values	Description
eth	n	wan_type	0/1/2/3/4	0: static ip 1: dynamic ip 2: pppoe 3: pptp 4: l2tp
eth	n	conn_ctl	0/1/2	0: auto 1: demand 2: manual in dynamic ip, pppoe, l2tp, pptp wan type
eth	n	max_idle_time		

## wan\_type: static ip

Entity	Instance	Parameter	Values	Description
eth	n	ipaddr	valid ip address	
eth	n	mask	valid subnet mask	
eth	n	gateway	ip address	
eth	n	dnserver	ip address	
eth	n	secdns	ip address	
eth	n	mtu	value	0: auto
eth	n	do_nat	0/1/2	0: disable 1: ip 2: ip and port

## network monitoring

Entity	Instance	Parameter	Values	Description
eth	n	nm	on/off	
eth	n	nm_mode	0/1	0: dns query: 1: icmp checking
eth	n	loading_check	on/off	
eth	n	check_interval	val	second
eth	n	timeout		second
eth	n	latency_threshold		ms
eth	n	fail_threshold		times
eth	n	target1	1/2/3/4	1: dns1 2: dns2 3: gateway 4: other host
eth	n	target2	1/2/3/4	
eth	n	other_host1	ip	
eth	n	other_host2	ip	

eth	n	igmp	0/1/2/3/4	0: disable 1: auto 2: igmp v1 3: igmp v2 4: igmp v3
eth	n	wan_ip_alias	on/off	
eth	n	wan_ip_alias_ip	ip	
eth	n	hostname	name	
eth	n	isp_reg_mac	mac	

### wan\_type: pppoe

Entity	Instance	Parameter	Values	Description
eth	n	ipv6_dual_stack	on/off	
ppp	n	username	str_username	
ppp	n	password	str_pwd	
eth	n	service_name	name	
eth	n	assigned_ip	ip	

### wan\_type: pptp

Entity	Instance	Parameter	Values	Description
eth	n	ip_mode	0/1	0: dynamic ip address 1: static ip address

### pptp/static ip address

Entity	Instance	Parameter	Values	Description
ppp	n	IPAddr	ip	
ppp	n	mask	mask	
ppp	n	gateway	ip	
ppp	n	server_ip_na	str_ip_nam	
ppp	n	connection_id	conn_id	

## wan type : 3g/4g

Entity	Instance	Parameter	Values	Description
sim	n	preferred_sim	0/1/2/3	0: sim a first 1: sim b first 2: sim a only 3: sim b only
sim	n	profile_a	0/1	0: auto-detection 1: Manual-configuration
sim	n	profile_b	0/1	0: auto-detection 1: Manual-configuration

## auto-detection

Entity	Instance	Parameter	Values	Description
sim	n	pin_code_a	pin_code	
sim	n	pin_code_b	pin_code	

## Manual-configuration

Entity	Instance	Parameter	Values	Description
<del>sim</del>	<del>n</del>	<del>country_a</del>	<del>0~N</del>	<del>0~N maps to support country</del>
<del>sim</del>	<del>n</del>	<del>service_provider_a</del>	<del>0~N</del>	<del>0~N map to support Service Provider</del>
sim	n	apn_a	str_apn	
sim	n	dial_num_a	dial_num	
sim	n	account_a	account	3g/4g



sim	n	password_a	passwd	3g/4g
sim	n	auth_a	0/1/2	0: auto 1: pap 2: chap
sim	n	dns1_a	ip	
sim	n	dns2_a	ip	

table 1 sim A

Entity	Instance	Parameter	Values	Description
<del>sim</del>	<del>n</del>	<del>country_b</del>	<del>0~N</del>	<del>0~N maps to support country</del>
<del>sim</del>	<del>n</del>	<del>service_provider_b</del>	<del>0~N</del>	<del>0~N map to support Service Provider</del>
sim	n	apn_b	str_apn	
sim	n	dial_num_b	dial_num	
sim	n	account_b	account	3g/4g
sim	n	password_b	passwd	3g/4g
sim	n	auth_b	0/1/2	0: auto 1: pap 2: chap
sim	n	dns2_a	ip	
sim	n	dns2_b	ip	

table 2 sim B

Entity	Instance	Parameter	Values	Description
sim	n	connection_control	0/1/2	0: auto-reconnect 1: connect-on-demand 2: connect-manual
sim	n	max_idle_time	value	second

## 1.2. LAN & VLAN

### 1.2.1. Ethernet LAN

Entity	Instance	Parameter	Values	Description
eth	n	ipaddr	valid ip address	
eth	n	mask	valid subnet mask	
Entity	Instance	Parameter	Values	Description
apply	lan_ip			apply LAN IP alter

## 1.3. WiFi

### 1.3.1. Configuration

#### Basic Configuration

Entity	Instance	Parameter	Values	Description
wifi	0	wps	on/off	
wifi	0	conf_status	0/1	0: set 1: release
wifi	0	conf_mode	0/1	0: registrar 1: enrollee
wifi	0	generate_pin_code	on	
wifi	0	allow_sta_pin_code		
wifi	0	wps_trigger	on	
wifi	0	wps_status	?	
apply	wps			

## 2.4G WiFi Configuration

Entity	Instance	Parameter	Values	Description
wifi	0	enable	on/off	
wifi	0	op_mode	0/1/2	0: ap router 1: wds only 2: wds hybrid
wifi	0	lazy_mode	on/off	
wifi	0	green_ap	on/off	
wifi	n	ap_enable	on/off	n: 1 ~ 8 1: VAP 1 2: VAP 2 ... 8: VAP 8
wifi	n	ap_max_enable	on/off	
wifi	n	ap_max	num	1 ~ 16
wifi	0	schedule	index	
wifi	n	ssid		
wifi	n	ssid_broadcast	on/off	
wifi	n	wlan_partition	on/off	
wifi	0	channel	0 ~ 11	0: auto 1: channel 1 ... 11: channel 11
wifi	0	wifi_system	0 ~ 5	0: 802.11b 1: 802.11g 2: 802.11n 3: 802.11 b/g 4: 802.11 g/n 5: 802.11 b/g/n
wifi	n	auth	0~8	0: open 1: shared 2: auto 3: wpa-psk

				4: wpa 5: wpa2-psk 6: wpa2 7: wpa-psk/ wpa2-psk 8: wpa/wpa2
wifi	n	en_8021x	on/off	only Authentication is: open auto
wifi	n	encrypt	0 ~ 4	0: none 1: WEP 2: TKIP 3: AES 4: TKIP/AES
wifi	n	wepkey_type	0/1	0: HEX 1: ASCII
wifi	n	wepkey		HEX: 10 or 26 ASCII: 5 or 13
wifi	n	pskey		length: 8 ~ 63
wifi	n	radisu_server_ip		
wifi	n	radisu_server_port		1 ~ 65535
wifi	n	radisu_server_key		
apply	wifi_conf			

### 1.3.2. Wireless Client List

Entity	Instance	Parameter	Values	Description
wifi	0	wc_list	0 ~ 8	list wireless clients 0: all 1: vap1 ... 8: vap8

### 1.3.3. Advanced Configuration

Entity	Instance	Parameter	Values	Description
wifi	0	op_band	0	0: 2.4g
wifi	0	beacon_interval		1 ~ 1000 msec
wifi	0	dtim_interval		1~255
wifi	0	rts_threshold		1 ~ 2347
wifi	0	frag		256 ~ 2346
wifi	0	wmm	on/off	
wifi	0	short_gi	0/1	0: 800 ns 1: 400 ns
wifi	0	tx_rate	0	0: best
wifi	0	rf_bandwidth	0/1/2	0: ht20 1: ht40 2: auto
wifi	0	transmit_power	0/1/2/3	0: 100% 1: 50% 2: 25% 3: 12%
apply	wifi_conf			

## 1.4. IPV6

Current ipv6 has no alter command, after enter ipv6 command, need reboot.

### 1.4.1. Configuration

Entity	Instance	Parameter	Values	Description
ipv6	0	enable	on/off	
ipv6	0	wan_conn_type	0/1/2/3/4/5	0: static ipv6 1: dhcpv6 2: pppoev6 3: 6to4 4: 6in4

## static ipv6

Entity	Instance	Parameter	Values	Description
ipv6	0	ipaddr		
ipv6	0	prefix_len		
ipv6	0	gateway		
ipv6	0	dnsserver		
ipv6	0	secdns		
ipv6	0	mld_snooping	on/off	
ipv6	0	ds_lite	on/off	
ipv6	0	ds_lite_opt	0/1	0: dynamic 1: static
ipv6	0	ds_lite_sip	ip_addr	ds_lite_opt: static
ipv6	0	g_addr		
ipv6	0	auto_conf_en	on/off	
ipv6	0	auto_conf_type	0/1	0: stateless 1: stateful
ipv6	0	ar_start	str	
ipv6	0	ar_end	str	
ipv6	0	ad_lifetime		seconds

## dhcipv6

Entity	Instance	Parameter	Values	Description
ipv6	0	dnsfrom	0/1	0: from server 1: specific dns
ipv6	0	dhcp_dns1		
ipv6	0	dhcp_dns2		

## pppoev6

Entity	Instance	Parameter	Values	Description
ipv6	0	username		
ipv6	0	password		
ipv6	0	service_name		
ipv6	0	mtu		

## 6to4

Entity	Instance	Parameter	Values	Description
ipv6	0	6to4dns1		
ipv6	0	6to4dns2		
ipv6	0	6to4_g_addr		

## 6in4

Entity	Instance	Parameter	Values	Description
ipv6	0	r_ipv4_addr		
ipv6	0	l_ipv6_addr		
ipv6	0	6in4_dns1		
ipv6	0	6in4_dns2		

## 1.5. NAT/Bridging

### 1.5.1. Configuration

Entity	Instance	Parameter	Values	Description
nb	0	loop_back	on/off	
apply	nb_conf			

## 1.5.2. Virtual server & Virtual Computer

### Virtual Server List

Entity	Instance	Parameter	Values	Description
nb	0	vs_list	?	
nb	n	vs_public_port		
nb	n	vs_server_ip		
nb	n	vs_private_port		
nb	n	vs_protocol	0/1/2	0: BOTH 1: TCP 2: UDP
nb	n	vs_schedule	index	
nb	n	vs_enable	on/off	
nb	0	vs_del	n	
apply	vs			

### Virtual Computer List

Entity	Instance	Parameter	Values	Description
nb	0	vc_list	?	
nb	n	vc_global_ip		
nb	n	vc_local_ip		
nb	n	vc_enable	on/off	
nb	0	vc_del	n	
apply	vc			

## 1.5.3. Special AP & ALG

### Configuration

Entity	Instance	Parameter	Values	Description
nb	0	alg_enable	on/off	
apply	nb_alg			



## Special AP Rule Configuration

Entity	Instance	Parameter	Values	Description
nb	0	ap_list	?	
nb	n	ap_trigger_port		
nb	n	ap_income_port		
nb	n	ap_schedule	index	
nb	n	ap_enable	on/off	
nb	0	ap_del	n	
apply	ap			

### 1.5.4. DMZ

#### DMZ

Entity	Instance	Parameter	Values	Description
nb	0	dmz_enable	on/off	
nb	0	dmz_ip		
apply	nb_dmz			

#### dhcp relay

Entity	Instance	Parameter	Values	Description
nb	0	dr_enable	on/off	
nb	0	dr_server_ip		
apply	nb_dr			

## 1.6. Routing

### 1.6.1. Static Routing

Entity	Instance	Parameter	Values	Description
routing	0	static_route	on/off	
Entity	Instance	Parameter	Values	Description
routing	n	dip		
routing	n	mask		
routing	n	gw		
routing	n	iface	0 ~ 7	0: auto 1: wan-1 2: wan-2 3: wan-3 4: lan 5: vlan-1 6: vlan-2 7: vlan-3
routing	n	rule_en	on/off	
routing	0	del	n	
routing	0	rs_list	?	list static routing rules
apply	routing			apply rule list

### 1.6.2. Dynamic Routing

#### rip

Entity	Instance	Parameter	Values	Description
routing	0	rip_op	0/1/2	0: disable 1: rip v1 2: rip v2

## ospf

Entity	Instance	Parameter	Values	Description
routing	0	ospf_en	on/off	
routing	0	ospf_backbone_subnet		
routing	n	ospf_area_subnet		
routing	n	ospf_area_id		
routing	n	ospf_area_en	on/off	
routing	0	ospf_del	n	
routing	0	ospf_list	?	list ospf rules

## bgp

Entity	Instance	Parameter	Values	Description
routing	0	bgp_en	on/off	
routing	0	bpg_self_id		
routing	n	bpg_nb_ip		
routing	n	bgp_nb_id		
routing	n	bgp_nb_en	on/off	
routing	n	bgp_del	n	
routing	0	bpg_list	?	list bgp rules
apply	bgp_del			

### 1.6.3. Routing Information

Entity	Instance	Parameter	Values	Description
routing	0	routing_table	?	
routing	0	routing_info	?	

  

Entity	Instance	Parameter	Values	Description
apply	routing			apply routing alter

## 1.7. Client/Server/Proxy

### 1.7.1. Dynamic DNS

#### Pre-defined Domain Name List

Entity	Instance	Parameter	Values	Description
dydns	0	dn_list	?	
dydns	n	dn		
dydns	n	dn_ip		
dydns	n	dn_en	on/off	
dydns	0	del	n	
apply	dn			

#### Dynamic DNS

Entity	Instance	Parameter	Values	Description
dydns	0	enable	on/off	
dydns	0	provider	0/1/2/3/4	0: DynDNS.org (Dynamic) 1: DynDNS.org (Custom) 2: No-IP.com 3: TZO.com 4: dhs.org
dydns	0	hostname		
dydns	0	username		
dydns	0	password		
apply	ddns			

## 1.7.2. DHCP Server

Entity	Instance	Parameter	Values	Description
dhcp	0	list	?	
dhcp	n	server_name		
dhcp	n	lan_ip		
dhcp	n	mask		
dhcp	n	ip_start		
dhcp	n	ip_end		
dhcp	n	lease_time		300 ~ 604800 seconds
dhcp	n	domain_name		
dhcp	n	dns1		
dhcp	n	dns2		
dhcp	n	wins1		
dhcp	n	wins2		
dhcp	n	gw		
dhcp	n	enable	on/off	
dhcp	0	del	2/3/4	
dhcp	0	fix_map_list	?	
dhcp	n	fix_map_mac		
dhcp	n	fix_map_ip		
dhcp	n	fix_map_en	on/off	
dhcp	0	fix_map_del	n	
apply	fix_map			